

6. MASS AND BALANCE

6.1 EQUIPMENT LIST ENTRIES

System/Equipment Designation	Part No.	Mass (kg)	Arm (mm)	Massmoment (kgmm)
Litter Rails-Narrow, LH Litter Rails-Narrow, RH	105-83921 105-83932	5.8 5.5	3400 3600	19720 19800
Litter Rails-Narrow, LH Litter Rails-Narrow, RH	D134-260 D134-658	5.8 5.5	3200 3600	18560 19800
Litter Rails-Narrow, LH Litter Rails-Narrow, RH	105-83923 105-83934	5.8 5.5	3400 3600	19720 19800
Litter Rails-Narrow, LH Litter Rails-Narrow, RH	D136-156 D136-157	5.8 5.5	3200 3600	18560 19800
Litter Rails-Narrow, LH Litter Rails-Narrow, RH	D136-210 D136-211	10.3 8.8	3300 3600	33990 31680
Litter Rails-Narrow, LH Litter Rails-Narrow, RH	D134-221 D134-222	6.0 6.0	3200 3200	19200 19200
– Litter Adapters, 2 each rail set		2.4	3600	8640
NOTE Mass of 2 litter adapters is included in mass of each above listed rail set.				
Litter Rails-Wide, LH Litter Rails-Wide, RH	105-83901 105-83908	5.3 5.8	3500 3700	18550 21460
Litter Rails-Wide, LH Litter Rails-Wide, RH	105-83913 105-83917	(5.7) (4.2)	(3400) (3500)	(19380) (14700)
Installation Provisions, LH Installation Provisions, RH	105-84002 105-84007	0.4 0.1	3600 3800	1440 380
Installation Provisions, LH Installation Provisions, RH	105-84012 105-84017	(0.4) (0.1)	(3500) (3600)	(1400) (360)
NOTE Above values in parentheses apply to Model S Variants.				

7. SYSTEM DESCRIPTION

The Litter Installation allows for transporting a maximum of two NATO standard litters on special rails located on the cargo compartment floor. The rails are available in sets providing for separate LH and/or RH litter installations. Normally the RH rail set is shorter than the LH rail set to provide space for a medical attendant seat located directly aft of the pilot seat.

Each set comprises two rails, locking devices and installation hardware. Litters are not included with the sets.

The narrow rail sets additionally have two litter adapters that are secured to the feet of a litter. These adapters are then slid onto the rails and secured with quick-release pins.

Adapters are not necessary with the wide rail sets. The four legs on each litter are secured direct to the rails with adjustable locking blocks.

